

USER MANUAL



FOR

DENSION DAB REMOTE II CONTROLLER

DENSION
LEADING IN CONNECTED ENTERTAINMENT

1. INTRODUCTION

The Bluetooth remote control for DAB is an optional accessory for the Denon DAB+A and DAB+M devices. The remote control makes the usage of the DAB devices as simple as the usage of an FM stereo.

1.1 First steps

If you plan on using your DAB device together with the remote control but without the DAB application, first you need to set up your DAB device. To do that, please follow these steps:



Bluetooth pairing:

The remote control will connect automatically to the nearest DAB+A or DAB+M device.

Setting FM frequency:

Manual Scanning

In order to set the FM frequency, you need to follow the next steps:

- ▶ Turn the ignition ON,
- ▶ Press and hold the  button for 3 seconds,
- ▶ Enter the frequency (from 87.6 [876] to 107.9 [1079]),
- ▶ Press the  button to store the valid frequency,
- ▶ Switch to the selected frequency on your radio.

Automatic Scanning

You can also start an automatic FM frequency scan. To use this option, you need to do the following:



- ▶ Turn the ignition ON,
- ▶ Press and hold the  button for 3 seconds,
- ▶ Press the  button.

After these steps, the device will be looking for a free frequency and will set it automatically. This frequency can be found if you do an FM scan with your radio.

1.2 Managing DAB+

You can perform a DAB scan by pressing the  button. During the scanning process you should see 'DAB scan' on the radio screen.


Navigation between stations

By pressing the  and  buttons, you can jump to the next or previous station. If you press and hold these buttons, you can skip five stations at a time (alphabetically).


Presets

You can store presets to button 1-9. To store the currently played station, you need to press and hold one of the numerical buttons for 3 seconds. After this, you can switch to that station directly by short pressing the same button.





1.3 Managing sources

With the  button you can toggle between three available sources DAB, AUX and Bluetooth audio (DAB+M only).



Auxiliary sources

The device gives you the possibility to listen to music from an external source through a 3,5mm Jack connector. In order to mute the DAB radio and use the Auxiliary input of the device, you need to press the  button. In this mode you should see "AUX" on the RDS display.

Bluetooth audio sources (DAB+M only)

It is also possible to switch to Bluetooth audio source with the  button. If this is the active source then you will be able to listen to all the music stored on your phone or you can listen online streams from your phone through the DAB+M on your head unit. In this mode you can use the  and  and the  buttons of the remote to control the music playback from your phone.

Hands free calls (DAB+M only)

In case of incoming hands free calls, you can pick up the call by pressing the  button and hang up or reject the call with the  button.

2. IMPORTANT NOTES

Please always consider safety first and comply with the traffic regulations and laws that apply. Do not use your phone if it can distract your attention from driving.

3. DISCLAIMER AND WARRANTY

If your product begins to behave in an unpredictable way, please immediately disconnect the device physically and have it checked by a qualified electrotechnician. Dension and its authorized distributors, as well as retailers are not liable for any incidental, consequential or indirect damages or loss and do not assume liability for any diagnostic fees. Using handheld devices while driving may be subject to government legislations. Please make sure that using a Dension device is in line with the applicable traffic laws. Dension does not assume liability for events resulting from any illegal or irresponsible usage of these handheld devices.

Dension reserves the right to modify its products or specifications without prior notice.

WARRANTY

Dension devices carry a one-year limited warranty that protects you from defects in material and workmanship of products sold by Dension or its authorized distributors and retailers. Dension does not warrant any installation work or assume liability for any damage caused by negligence, improper installation or operation. For warranty claims, proof of purchase is required.

SUPPORT

If you need further assistance in using your Dension product, please contact your local supplier or visit our website at www.dension.com

For technical support please contact us through the listed possibilities on www.dension.com/automotive/support



BRC-9201-1

DENISON
LEADING IN CONNECTED ENTERTAINMENT